

FIG. 1


VPS OVERVIEW
START
20
RECEIVE CALL
22
DIVERT FLAG SET ?
Y
24
NORMAL DEPOSIT MODE
A
N
26
CLI ?
Y
28
NORMAL RETRIEVAL MODE
B
N
30
MAILBOX No. ?
Y
32
INT. CALL ?
Y
34
INT. MODE
C
N
NORMAL RETRIEVAL MODE
36
B
N
38
PROMPT FOR MAILBOX No.
40
RECEIVE NUMBER
42
VALID MAILBOX No. ?
N
Y
43
MAILBOX AVAILABLE IN THIS VPS ?
Y
45
INT. CALL ?
Y
46
INT. MODE
C
N
44
CALL DROP BACK
END
NORMAL RETRIEVAL MODE
48
B

FIG. 2

NORMAL DEPOSIT MODE



FIG. 3


NORMAL RETRIEVAL MODE
B
66
PLAY RETRIEVAL MESSAGE
68
STAR KEY PRESSED ?
Y
N
70
PROMPT FOR MAILBOX No.
72
RECEIVE MAILBOX No.
74
VALID MAILBOX No. ?
N
Y
76
MAILBOX IN CURRENT VPS?
Y
N
78
CALL DROP BACK
END
80
MAILBOX No. AVAILABLE ?
N
82
USE CLI TO IDENTIFY MAILBOX No.
Y
84
PROMPT FOR PIN CODE
86
RECEIVE PIN CODE
87
STAR KEY PRESSED ?
Y
N
88
VALID PIN NUMBER ?
N
Y
90
ACCESS MAILBOX
92
PLAY MESSAGES TO BE RETRIEVED
END

FIG. 4


INTERNATIONAL MODE
(DEPOSIT + RETRIEVAL)
C
ACCESS MAILBOX
94
PLAY DEPOSIT MESSAGE
96
STAR KEY PRESSED ?
98
Y
100
NORMAL RETRIEVAL MODE
END
N
RECEIVE + STORE MESSAGE
102
END

FIG. 5